

- ① - Procedere al montaggio seguendo le operazioni in ordine numerico progressivo.
- ⓖⓑ - Proceed with assembling following the operations in progressive numerical order.
- ⓓ - Arbeitsgänge in numerischer ordnung ausführen, um das gerät zu installieren.
- Ⓡⓞ - Производите установку в порядке увеличения обозначенных выше номеров.
- ⓕ - Il faut procéder a le montage exécutant les operatoins par l'ordre numerique progressif.
- Ⓟ - Proceder a montagem segundo as istruções em ordem numerica progressiva.
- ⓔⓢ - Proceder al montaje siguiendo las operaciones en orden numerico progresivo.

Proceed with assembling following the operations in progressive numerical order.
 Il faut procéder a le montage exécutant les operatoins par l'ordre numerique progressif.

ATTENTION
 The safety of the appliance is granted only if it is properly used according to the following instructions. Which are to be kept.

WARNING
 Always disconnect from the power supply before installing or performing any maintenance operations.

WIRING INSTRUCTIONS
 1-Strip the wire coming from the junction box and from the fixture
 twist them together with the white wires, insert a connector and twist tightly

2-Do the same procedure for the black wire

3-If the cable coming from the structure is flat strip the lined or rubbered wire,
 twist it with the white wire, insert a connector and twist tightly

4-Strip the yellow and green wire, twist them together,
 insert a connector and twist tightly

ATTENTION
 La sécurité de cet appareil n'est garantie que si l'on respecte
 les instructions suivantes

Par conséquent, il est important de les conserver soigneusement.

INSTRUCTIONS DE MONTAGE
 1- Dénuder les fils provenant de la boîte de jonction et de la structure, enrôler
 les fils blancs entre eux, introduire un connecteur et tordre avec force.

2- Effectuer la même opération avec le fil noir.

3- Si le câble de la structure est du type plat, dénuder le fil avec la règle ou la
 saillie, l'enrouler avec le blanc, introduire un connecteur et tordre avec force.

4- Dénuder les fils de terre jaune et vert, les enrôler entre eux, introduire un
 connecteur et tordre avec force.

